

# Frog mineral System

## Water balance guidelines:

- Free Chlorine           0.5-1.0
- Calcium hardness     200-400
- Alkalinity               100-150
- pH level                 7.2-7.6
- Stabilizer               30-50

Keep pump and filter running 24hrs a day and seven days a week.

## Start-up

1. Balance Water
2. Add Start-up kit (Premix each chemical separately and add 15 minutes apart)
  - 2lbs Turbo Shock
  - 2 containers Algistat
  - 1 container Metal Control Agent
3. Add Clarifier if needed
4. Add Mineral Pac to reservoir
5. Add Frog BAM algaecide (90 day supply) Run for 2-6 hours
  - 1qt. up to 15,000 gallons
  - 2qts. per 17,500-30,000 gallons
6. Test stabilizer, add if necessary
7. Add chlorine BAC Pac

## Weekly

1. Balance water
2. Shock                    Add Chemicals 15min apart
  - \*\*Turbo Shock
  - 1lb per 10,000 gallons
3. Clarifier
  - \*\*Natural Chemistry 'Clear'
  - 1oz. per 7,000 gallons

## Remember

- a. Replace mineral Pac each season
- b. Algaecide - - replace every 90 days
  - Frog BAM
- c. Chlorine BAC Pac
  - Check every 2-3 weeks

| Monday | Tuesday | Wednesday | <u>Thursday</u>      | Friday | Saturday         | <u>Sunday</u>                                   |
|--------|---------|-----------|----------------------|--------|------------------|---|
|        |         |           | Test & Balance Water |        | Enjoy the Pool!! | Test & Balance Water.<br>♦ Shock<br>♦ Clarifier |

Replace:     --Chlorine BAC Pac (2-3 Weeks)           --Mineral Pac (Every Season)  
                   --BAM Algaecide (90 days)